USER MANUAL

IN THE BOX

Table 1: Specifications

COOL WHITE
CCT: 5700-6500K CRI: 70

HIGH 100 lumens	500 cd
MEDIUM 10 lumens	50 cd
MOONLIGHT 1.5 lumens	3 cd
BEDLIGHT 4 lumens	1 cd

1300m	70m	IPX5	1.5m
1LM@1.5~2M/22.5mm 0.LE.TQ=0.5CP/1M/22.5mm		30g/1.05oz (including Battery)	

Rechargeable Li-ion Battery
350mAh (3.7V 1.3WHr)

Working temperature
0°C~45°C (32°F~113°F)

* Above data are tested per IAREC0001-2.1 2009 standard in Bright Sun Lab for reference. The data are performed indoor under

Table 2: USB-C Charging Cable

Charge Type	USB-C
Cable Length	0.25m
Input	5V/1A
Charging Time	About 1.5 hours

Figure 1 Product overview

Figure 2 Charge

Figure 3 On/Off

Figure 4 Lockout / Unlock

Figure 5 Moonlight mode

Figure 6 Change brightness level

Figure 7 Strobe (White light mode only)

Figure 8 Red light mode

Figure 9 Switch between red and white light mode

Figure 10 Turn on white beacon

Figure 11 Turn on white light beacon

Figure 12 Battery indicator

CONTENTS

(EN) English 01
(CN) 简体中文 02
(FI) Finnish 03
(NO) Norwegian 04
(SV) Swedish 05
(NL) Nederlands 06
(PL) Polska 07
(DE) Deutsch 08
(HU) Magyarország 09
(RU) Русский 10
(ES) Español 11
(RO) Românesc 12
(UA) Українська 13
(JP) 日本語 14
(KR) 한국어 15
(TH) ไทย 16
(FR) Français 17
(IT) Italiano 18
(SK) Slovenskýjazyk 19
(PT) Português 20

Ocelip

A clip-on light with dual light sources.

1.3 Charge: red light mode, see Figure 10.
In the red light mode, press and hold for more than 0.5 second to switch to red light, release the button, and press and hold for more than 0.5 seconds to switch back to white light.

1.10 Turn on white light beacon, see Figure 11.
Turn on white light beacon by quickly pressing the button three times when the light is off or in red light mode. To exit the mode, simply press or press and hold the button.

2. Battery indicator, see Figure 12.

EN

DANGER
• Do not disassemble the product.
• Do not throw the product into the fire, it may cause the battery to burn or even explode; causing personal injuries or disaster.

CAUTION
• Do not look directly at the light source or shine it into your eyes, as this may cause temporary blindness or permanent damage to your eyes.
• Do not actively shine the lens, or shine the energy emitted from the light may cause the object to burn.
• Don't place, charge or use this light in a car when the temperature exceeds may exceed 60°C or in similar environments.
• Do not immerse the product in water or other liquid in a 5 meter/3 minutes depth.
• Do not place the light in a dusty environment as dust may enter the product and cause malfunction.
• The clip is magnetic, and the metal powder adsorbed on the surface will affect the function, please clean it immediately.

NOTICE
• Please only use the TYPE-C charging cable to charge the product to avoid damage.
• Charge the product completely before storing it for a long period.
• If the product is carried, transported, please lock the product.
• When the charging port is not in use, keep the dust cover closed to avoid dust or foreign objects from entering.

REMARK
• Do not put a hot light into any type of fabric bag or flexible plastic container.
• Rinse port bays.
• When the ambient temperature is below 0°C/32°F, the light can only output at the low and medium brightness mode.

EXCLUSION CLAUSE
Ocelip is not liable for damages or injuries caused resulting from the use or usage of the product inconsistent with the warnings in the manual, including but not limited to using the product inconsistent with the recommended/ideal usage mode.

(CN) 简体中文

多语言字典，参见 Table 3.

1. 产品参数参见 Table 1与Table 2。

2. 产品图示，参见Figure 1。

3. 操作指引：

3.1 开机，参见Figure 2。

3.2 关机，参见Figure 3。

按住按键开关，关机后，记忆当前模式。

3.3 切换红、白光模式，参见Figure 4。

3.4 锁定/解锁按键，参见Figure 5。

按住按键开关，持续3秒，锁定后，记忆当前模式。

3.5 使用夜光（红色）模式，参见Figure 6。

3.6 调节亮度，参见Figure 7。

3.7 闪烁（仅白光模式），参见Figure 8。

3.8 切换红、白光模式，参见Figure 9。

3.9 开启白光信标，参见Figure 10。

3.10 开启白光照明灯，参见Figure 11。

4. 电量指示灯说明，参见Figure 12。

FI

Turvallisuus
• Ole hyvä ja lue ohjeet ennen laitteen käyttöä.
• Ennen ensimmäistä kertaa käytettäessä ja 2-3 kertaa vuodessa ladattava akku.
• Ei saa purkaa, muuntaa, muokata tai kuormittaa laitteen akkua.
• Ei saa altistaa laitetta tulelle, räjähdysvaarasta.
• Ei saa altistaa laitetta kosteudelle, ei saa upottaa vedenpinnan alle 5 metrin syvyyteen 3 minuutin ajaksi.
• Ei saa altistaa laitetta korkeille lämpötiloille, ei saa ylittää 60°C lämpötilaa.
• Ei saa altistaa laitetta pölyisille olosuhteille.
• Ei saa altistaa laitetta voimakkaille pistemäisille valonlähteille, ei saa suunnata valonlähdettä ihmisiä tai eläimiä kohti.
• Ei saa altistaa laitetta voimakkaille magneettikenttiä.
• Ei saa altistaa laitetta voimakkaille pölyisille olosuhteille.
• Ei saa altistaa laitetta voimakkaille magneettikenttiä.
• Ei saa altistaa laitetta voimakkaille pölyisille olosuhteille.
• Ei saa altistaa laitetta voimakkaille magneettikenttiä.
• Ei saa altistaa laitetta voimakkaille pölyisille olosuhteille.

Huomautus
• Ole hyvä ja käytä ainoastaan USB-C-kaapelia.
• Ole hyvä ja lataa tuote ennen pitkän säilytyksen.
• Lukitse tuote, jos sitä kuljetetaan tai kuljetetaan.
• Pidä pölysuojus suljettu, kun et käytä sitä, jotta pölyä ja muut ulkoiset esineet eivät pääse sisälle.

Huomautus