


Neomounts®



LED-W450BLACK

EN TV wall mount

NL TV wandsteun

DE TV Wandhalterung

FR Support mural pour TV

IT Supporto TV a parete

ES Soporte de pared para TV

PT Suporte de parede para TV

DK Vægbeslag TV

NO TV veggfeste

SE TV-väggfäste

FI TV seinäteline

PL Uchwył ścienny do TV

CS Nástěnný držák na TV

SK Nástenný držiak na TV

RO Suport TV de perete



Tool

Drill



100x100 -
400x400 mm



0-35 kg




3 cm

LED-W450BLACK

PARTS



A. (x2)



B. (x1)



C. 4mm
(x1)



M-A. M6x14
(x4)



M-B. M8x16
(x4)



M-C. M6x30
(x4)



M-D. M8x35
(x4)



M-E. D8
(x4)



M-F. (x4)



M-G. (x4)



W-A. (x4)



W-B. (x4)






W-C. (x4)

STEP 1





A

- EN Install the wall plate on a wooden stud
- NL Bevestig de muurbeugel aan een houten balk
- DE Installieren Sie die Halterungsplatte auf einem Holzbalken
- FR Installez la plaque murale sur un mur en bois ou en plaque au platre
- IT Installare la piastra di parete su un perno in legno
- ES Fije el soporte de pared a una viga de madera
- PT Instale a placa do suporte de parede num poste de madeira
- PL Zamontuj płytę ścienną do drewnianej powierzchni




STEP 1 B

- EN Install the wall plate on a solid brick or concrete wall
- NL Bevestig de muurbeugel aan een stevige stenen of betonnen muur
- DE Installieren Sie die Halterungsplatte an einer soliden Ziegel- oder Betonwand
- FR Installez la plaque murale sur un mur de brique ou de béton
- IT Installare la piastra di parete su un muro di mattoni o cemento
- ES Fije el soporte de pared a una piedra sólida o muro de hormigón
- PT Instale a placa do suporte de parede numa parede sólida de tijolo ou betão
- PL Zamontuj płytę ścienną do ściany z cegły lub betonu




STEP 2

- EN Install the adapter brackets
 NL Installeer de adaptersteunen
 DE Installieren Sie die Adapterhalterungen
 FR Installez les supports d'adaptation
 IT Installare le staffe di adattamento
 ES Instale los soportes adaptadores
 PT Instalar os suportes do adaptador
 PL Zainstaluj wsporniki adaptera




STEP 3

- EN Attach the screen to the bracket, secure and level it
 NL Bevestig het scherm aan de beugel, zet vast en lijn uit
 DE Befestigen Sie den Bildschirm an der Halterung, sichern Sie sie und richten Sie sie aus
 FR Fixer l'écran au support, le fixer et le niveler
 IT Fissare lo schermo alla staffa, fissarlo e livellarlo
 ES Fije la pantalla al soporte, fjéla y nivélela
 PT Fixar o ecrã no suporte, fixá-lo e nivelá-lo
 PL Przymocuj ekran do wspornika, zabezpiecz go i wypoziomuj



STEP 4

- EN Adjust the mount to the desired position
- NL Stel de steun in op de gewenste positie
- DE Stellen Sie die Halterung auf die gewünschte Position ein
- FR Ajustez le support à la position souhaitée
- IT Regolare il supporto nella posizione desiderata
- ES Ajuste el soporte a la posición deseada
- PT Ajuste o suporte na posição desejada
- PL Dostosuj pozycję uchwytu do twoich wymagań



STEP 5

- EN Pull the straps to release the screen
- NL Trek aan de riempjes om het scherm los te koppelen
- DE Ziehen Sie an den Bandern, um den Bildschirm zu lösen
- FR Tirez les sangles pour déconnecter l'écran
- IT Tirare le cinghie per rilasciare la schermo
- ES Tire de las correas para desconectar la pantalla
- PT Puxe a alça para soltar a tela
- PL Pociągnij pasek, aby zwolnić telewizor

