










Dell Pro P 24 USB-C Hub Konferenz-Monitor
P2426HEB
Schnellstartanleitung









2



3





4




1

















1







2




3












Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Reihenschaltung



Dell.com/support/P2426HEB